

USER GUIDE



Step by step



I. Connect the transmitter unit to your device via the HDMI port and to a power source using the USB Cable



3. Ensure the two units have a line of sight less than 30m and enjoy wireless transmission of uncompressed HD video streaming



2. Connect the receiver unit to your screen via the HDMI port and to a power source using the USB cable. (user needs to select correct AV input)



Please follow to download our User Guide in your language French translations German translations Spanish translations Italian translations





FAST, STABLE CONNECTION



4K RESOLUTION



SUPPORTS AUDIO



30M LINE-OF-SIGHT IN ROOM SIGNAL COVERAGE



PLUG IN AND PLAY



UNCOMPROMISING QUALITY